Connecting Trailer To Your Vehicle

- Reverse your vehicle slowly toward the trailer and align tow ball directly under the trailer coupling
- Use jockey wheel to lower the trailer coupling fully onto the tow ball. **Must be 50mm tow ball**
- Close the coupling latch and connect R clip
- Lift the trailer slightly with jockey wheel to confirm it is locked onto the tow ball then raise and swing up jockey wheel make sure it cannot drop while driving
- Attach safety chain(s) crossing under drawbar, attach securely to the vehicles tow points, chains must not drag on the ground
- Connect trailer plug into your vehicle socket, ensure it is firmly seated, **plug is 7 pin flat**

Before Driving

- Check coupling is locked
- Chain(s) are attached correctly
- Lights are working (brakes, indicators, tail lights)
- Trailer is level and secure

Disconnecting Trailer From Your Vehicle

- Park on level ground, apply vehicle handbrake, chock trailer wheels
- Wind down jockey wheel until it supports the trailer
- Disconnect trailer plug from vehicle
- Disconnect chain(s) from vehicle
- Remove R clip and release coupling latch
- Wind the jockey wheel to lift trailer off the tow ball
- Slowly drive vehicle forward clear of the trailer

Final Check

- Ensure trailer is stable and secure before leaving it